

Directions for use

1) Place A strains (male) on the headboard and the footboard of the bed at the desired point. Make a mark and put the screws.

2) Place B strains (female) on both side boards of the bed frame, with their arrows pointing up, to the desired point .Make a mark and put the screws.

3) Connect the two sides of the bed frame with the head board and the foot board of the bed, pushing downwards until they lock together.

4) To disassemble the bed, just press the safety button, unbuckle and pull upwards.

